
Navigation Handbook

Navigation System Quick Reference

Getting Around the System



Joystick and Enter button

Joystick – The Joystick has eight movements (Up/Down, Left/Right, and diagonal), and has the following functions:

- Highlights menu items, setup options and text items (Up/Down).
- Character and number input (Up/Down, Left/Right, and diagonal).
- Scrolling map position (Up/Down, Left/Right, and diagonal).

Enter button – Push the top of the Joystick. This has the following functions:

- Selects the highlighted menu item, setup option or text item.
- After scrolling the map, shows the map cursor location details highlighted in a text box. (Push ENTER again to select)



List button

Lists the turn information for the calculated route.



Clear button

The Clear button has the following functions according to the screen currently displayed:

- Returns to the previous menu, character input or text screen.
- Push and hold for two seconds to change the map orientation.



Repeat button

While under guidance, repeats the last audible instruction. If the manoeuvre point has been passed, the audible instruction for the next manoeuvre point will be heard.



On/Off button

Push ON/OFF at any time to turn the screen Off. The system continues to operate and to monitor vehicle position.

Push ON/OFF again to turn the screen back On. (The road safety caution screen is only displayed when the ignition is switched on.)



Menu button

Displays the Main menu. Highlight the option required using the Joystick (Up/Down) and push ENTER.



Map button

The Map button has the following functions.

- Returns to the map display, showing the current vehicle position, from any other screen, or after scrolling the map.
- While under guidance, toggles between map and arrow view.



Scale control

The Scale control (Up/Down) has the following functions.

- Changes the scale (Reduce/Enlarge) when a map screen is displayed.
- Displays more pages of text, when the scrolling arrows are displayed at the top or bottom of a screen.

Options Available Before Driving

Changing the Display Colour

MENU → Setup → Display Colour → Select Day, Night or Auto.

Selecting a Language

MENU → Setup → Language → Select a language.

Selecting the Guide Method

MENU → Setup → Guide Method → Select Hybrid, Arrow or Map.

Editing Memory Points

MENU → Option → Edit Memory Points → Select a point to edit or delete.

Editing Recent Destination Points

MENU → Option → Edit Recent Destination Points → Select a point to delete, or delete all points.

Options Available While Driving Under Guidance

Cancelling Guidance

MENU → Route → Cancel Current Destination → Confirm the on-screen prompt.

Avoiding Roads

MENU → Route → Avoid Roads → Select a road → Reroute → ENTER to Proceed.

Changing the Calculating Method

MENU → Route → Change Calculating Method → Select a method.

Changing Map Heading

CLEAR → Push and hold for two seconds to change the map orientation (north or vehicle heading to top of screen).

Repeating Voice Guidance

REPEAT → Repeats the last audible instruction.
(If the manoeuvre point has been passed, the audible instruction for the next manoeuvre point will be heard.)

Listing Turns Information

LIST → Displays the turn information for the calculated route.

Getting Started

To make a selection, highlight the item required using the Joystick, and push ENTER.

Initialisation

Jaguar Screen → Caution Screen → Map display.

Entering a Destination by Address

MENU → Destination → Address →
Street/City Name Input → Enter the address details →
Confirm Destination → ENTER to Proceed.

Entering a Destination to a City Centre

MENU → Destination → Map Cursor → City Name Input →
Enter the city name.
(The system defaults to the centre of the city entered.)

Storing a Frequently Used Location as a Destination

Enter the address details → Confirm Destination → Set Memory Point.


Selecting a Frequently Used Location as a Destination

MENU → Destination → Memory Points → Select a memory point → Confirm Destination → Set Memory Point.

Selecting a Point of Interest


MENU → Destination → Points of Interest →
Place Name Input/Category List → Select a point →
Confirm Destination → ENTER to Proceed.

Typical Guidance Screen



- A. Upper Message Area
- B. GPS Symbol
- C. Navigation symbol
- D. Map Scale
- E. Clock
- F. Lower Message Area
- G. Destination Information
- H. Map Orientation Symbol

Menu Structure





Navigation Handbook

JAGUAR CARS LIMITED, as manufacturers, are dedicated to the design and production of vehicles which meet the expectations of the world's most discerning purchasers.

To complement the features, systems and technology of your new vehicle we have produced this Navigation Handbook. In it we have undertaken to make the control of complex systems easy to understand and operate.

The information contained herein applies to a range of vehicles and not to a specific vehicle. For the specification of a particular vehicle, owners should consult their Jaguar Dealer.

The Manufacturer reserves the right to vary its specifications with or without notice, and at such times and in such manner as it thinks fit. Major as well as minor changes may be involved in accordance with the Manufacturer's policy of constant product improvement.

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted, in any form, electronic, mechanical, photocopying, recording or other means without prior written permission from the Service Division of Jaguar Cars Limited.

Contents

1. Introduction and controls

Introduction	1-1
Using the system	1-2
Safety information	1-2
Loading the map DVD	1-5
Control panel	1-5
Screen displays	1-6
Using the controls	1-10
Text input	1-12

2. Quick reference

Main features of the system	2-1
Route setting example	2-2
Menu structure	2-6

3. Operation

Getting started	3-1
Main menu	3-3
Destination menu	3-4
Setup menu	3-7
Option menu	3-10
Route menu	3-12

4. Route calculation and guidance

Route calculation	4-1
Route guidance	4-2
Screen guidance	4-3
Additional guidance features	4-4
Long-haul areas	4-5

A comprehensive index is located at the back of this handbook.

Introduction

This Jaguar navigation system assists the driver by providing a route to a selected destination. Guidance is given by means of audible instructions (voice guidance), complemented by map and turn information which is displayed on an LCD display on the front panel of the unit. Digital map information is held on a digital versatile disc (DVD), which is loaded into the navigation control unit housed in the luggage compartment.

The system has an extremely comprehensive range of features, yet is easy to use. Some time spent reading this handbook will ensure that the best results are obtained.

The LCD display provides full information for operating the system by means of menus, text screens and map displays. Screen selections are made by the controls on the front panel.

How the system works

The system uses signals from the Global Positioning System (GPS) satellites, which allow the approximate vehicle position to be calculated. This is combined with information from vehicle sensors and data from the map DVD to establish the true vehicle position.



WARNING:

1. The Database reflects reality as existing before you received the Database and it comprises data and information from government and other sources, which may contain errors and omissions. Accordingly, the Database may contain inaccurate or incomplete information due to the passage of time, changing circumstances, and due to the nature of the sources used. The Database does not include or reflect information on – inter alia – neighborhood safety; law enforcement; emergency assistance; construction work; road or lane closures; vehicle or speed restrictions; road slope or grade; bridge height, weight or other limits; road or traffic conditions; special events; traffic congestion; or travel time.
2. Only operate, adjust or view the system when it is safe to do so.
3. While the route is being calculated, the screen may show one of the following warnings, which must be observed.
 - 'Destination is located on a restricted road. Please follow traffic regulations.'
 - 'Destination is located on a restricted or private area. You may need permission. Push ENTER to continue.'

1-2 Introduction and controls

Using the system



Safety Information

The road safety caution screen is displayed each time the ignition is switched on, after pushing ENTER to select the Jaguar screen. The road safety caution screen gives the following information.

Most functions are inhibited while the vehicle is in motion.

Please read the handbook for operating instructions.

Always obey traffic regulations.

To use the system, push ENTER.

Caution: If the system is used for an extended period of time with the vehicle stationary, ensure that the engine is running, to avoid draining the battery.

For best results, always use the latest version of the map DVD (navigable map database). Map information is regularly updated, but all areas are not necessarily covered to the same level of detail. Some areas, in particular private roads, may not be included on the database (non-digitised roads).

While driving under route guidance, only follow an instruction when it is safe to do so, as the system cannot be aware of changing conditions, for example turn restrictions, roadworks or diversions. Use voice guidance as much as possible, and only view the display when driving conditions permit.

About this handbook

This handbook shows the on-screen menus, explains how to operate the controls, and gives an example showing how to set a destination. After becoming familiar with the controls, follow the on-screen menus and prompts, to operate the system as required.

To find a particular menu, use the Menu Structure on the card supplied with this handbook. This information is repeated on page 2-6.

Note: Throughout the handbook, the expression 'Select an item' (or similar wording), means 'Highlight the item using the joystick, and push ENTER'.

Using the system (continued)

Reception of GPS signals

GPS signals are highly directional and reception may occasionally be interrupted. Some examples of situations likely to cause problems are shown below.

- Inside tunnels.
- Inside buildings.
- Roads under raised highways.
- Densely tree-lined roads.
- Forest roads between mountains.
- Between tall buildings.
- Roads under cliffs.
- Metal objects placed on the rear parcel shelf.
- Fitting material to the rear screen containing metal foil.

Errors in vehicle position

Under certain driving conditions, it is possible that the vehicle position shown may be incorrect. Some examples are shown below.

- When the vehicle is transported by ferry or train.
- After vehicle battery removal or supply fuse failure.
- After the vehicle has been rotated on a turntable.
- Where there are two roads parallel to each other.
- Elevated roads in proximity to other roads.

The position will usually be corrected automatically. If the problem persists, consult your Jaguar dealer.

Route guidance precision

Under certain driving conditions, it is possible that the route guidance may be inaccurate. Some examples are shown below.

- Deviation from a route may cause incorrect guidance until the route has been recalculated.
- Route guidance may be given where no turn is required.
- If there is no road, or only a narrow track, to the final destination, guidance will be given to the nearest point possible.
- No guidance is given while reversing.
- If driving at high speed or on very dense road networks, it may not be possible to recalculate the route in time for the next instruction.
- On familiar roads, personal route preferences may not always be followed.

1-4 Introduction and controls

Using the system (continued)

Jaguar dealership locations

Details of Jaguar dealerships are held on the map DVD as a points of interest (POI) category. Certain dealers may be located in areas that are not fully mapped on the DVD. If a route is set to one of these dealers, guidance will only be possible to the nearest city centre, and a warning message will be displayed.

Map DVDs

To use the system in other countries or geographical areas, obtain the appropriate map DVD from your Jaguar dealer.

Screen cleaning

For approved screen cleaners, see your Jaguar dealer.

Clock

The time is shown on the screen in 12 hour format, except while a menu or text screen is being displayed. The correct time is maintained automatically from the GPS satellite signals and no manual adjustment is required.

Note: Ensure that the time zone and summer time settings are correct for the current vehicle location and time of year. See **Setup menu** on page 3-7.

Languages and distance units

The language used for the on-screen text and voice instructions can be selected from the list of available languages, see **Setup menu** on page 3-7.

Distances are shown on the screen either in Imperial units (miles and yards), or in Metric units (kilometres and metres). The distance units used are selected with the language. UK English has Imperial units, and all the European languages have Metric units.

Estimated time to destination

When a route is calculated, the estimated time required to drive the route is determined. This is based on the vehicle travelling at the speed limit applicable to each of the roads forming the route. While under guidance, the estimated time remaining is shown on the screen.


City name lists

For each city area, the first entry shows the city name only, and covers only the areas not included under the district entries. The subsequent entries show the city name followed by a district (suburb, industrial estate, town or village) within that city area, shown in brackets.

Road function layouts

The layout of complex road junctions may sometimes be shown in a simplified form.

Using the system (continued)




Loading the map DVD

Note: The ignition must be switched on (position 'I').

- 1 Locate the navigation unit (A), on the right-hand side of the luggage compartment above the sound system CD player
- 2 Open the front cover (B), using the recess on the top edge
- 3 If a DVD is already loaded, push the eject button (C) to eject it
- 4 Load the DVD with the printed side upwards (D). Do not allow moisture or foreign objects to enter the slot
- 5 Close the front cover (B).

Note: Ensure that an audio CD is not loaded into the navigation unit and vice versa. No damage will be done but the system will not operate.



Control panel

- A. Menu button
- B. List button
- C. Clear button
- D. Joystick and Enter button
- E. LCD display
- F. On/Off button
- G. Map button
- H. Repeat button
- I. Scale control

1-6 Introduction and controls

Screen displays



- F. Lower message area** – Shows details of the current vehicle location.
- G. Destination information** – While under guidance, shows the estimated time and distance to the end of the route, and the destination heading.
- H. Map orientation symbol** - Indicates that the map is displayed with either north or vehicle heading to the top of the screen

Map screens

A typical map display is shown, with a key to the main items of information.

- A. Upper message area** – While under guidance, shows the next street name on the route, or a text prompt. After driving off, the next turn symbol is displayed to the left of the text. (At the end of a route the destination symbol is displayed.)
- B. GPS symbol** – Indicates that the system is receiving information from GPS satellites. The symbol will be displayed in one of three colours, red, green or grey. See **GPS information** on page 3-11.

- C. Map position markers** – The map indicates the current vehicle position (navigation symbol). If the map is scrolled, the cross-wire marker is displayed. While the system is in use various markers are displayed see **Screen symbols** on page 1-8.
- D. Map scale** – Indicates the current zoom level. The scale length represents a distance of from $\frac{1}{30}$ mile to 100 miles (100 metres to 200 kilometres).
- E. Clock** – The time is displayed in 12 hour format.

Screen displays (continued)



AX 1-5

Arrow view screens

While under guidance, the route instructions can be displayed in diagrammatic form. A typical display is shown, with a key to the main items of information.

- A. Upper message area** - Shows the next street name on the route
- B. Distance to turn** - Indicates the distance to the next turn on the route. At 500 yards (500 metres) before the turn, the count-down bar graph is displayed.
- C. Clock** - The time is displayed in 12 hour format
- D. Lower message area** - Shows details of the current vehicle location on the route.
- E. Destination Information** - Shows the estimated time and distance to the end of the route, and the destination heading.

1-8 Introduction and controls

Screen displays (continued)

Screen symbols

The screen symbols used by the system are explained below.



Navigation symbol Indicates the current vehicle position and heading



Cross-wire marker – This symbol is displayed when the map is scrolled to select a destination or point (map cursor location).



Destination symbol – Indicates the current route destination.



Destination heading symbol Shows the current compass heading to the route destination. (A typical example is shown.)



Next turn symbol – Shows the action to be taken at the next manoeuvre point on the route ahead. (A typical example is shown.)




North up symbol Indicates that the map is displayed with north to the top of the screen.



Heading up symbol – Indicates that the map is displayed with the vehicle heading to the top of the screen. The position of the pointer indicates the direction of north on the map.

Screen displays (continued)



Scrolling indicators

The vertical indicators, when displayed at the right-hand side of a text screen, show that further pages of information are available. The information can be displayed as follows:

- Use the Scale control (Up/Down) to display a page (Previous/Next) of information
- Use the Joystick (Up/Down) to scroll through the information.



Menu screens

The screen shows the list of menu items

Highlight the menu item required using the Joystick (Up/Down) and press ENTER (If the desired menu item is not displayed, scroll the screen as required).

If a menu item cannot currently be selected, it is shown shaded out

The complete menu structure is shown on the card supplied with this handbook. This information is repeated on page 2-6.

1-10 Introduction and controls

Using the controls



Joystick and Enter button

Joystick – The joystick has eight movements (Up/Down, Left/Right, and diagonal), and has the following functions according to the screen currently displayed.

- Highlights menu items, Setup options and text items (Up/Down).
- Character and number input (Up/Down, Left/Right, and diagonal)
- Scrolling map position (Up/Down, Left/Right, and diagonal)

Enter button – Push the top of the joystick. This has the following functions.

- Selects the highlighted menu item, Setup option or text item
- After scrolling the map, shows the map cursor location details highlighted in a text box. (Push ENTER again to select, see **Confirm destination** on page 4-1.)

CLEAR

Clear button

The Clear button has the following functions according to the screen currently displayed:

- Returns to the previous menu, character input or text screen
- Push and hold for two seconds to change the map orientation (north or vehicle heading at top of screen).

LIST

List button

Lists the turn information for the calculated route.

REPEAT

Repeat button

While under guidance, repeats the last audible instruction. If the manoeuvre point has been passed, the audible instruction for the next manoeuvre point will be heard.

MENU

Menu button

Displays the Main menu (Destination, Setup, Option and Route). Highlight the option required using the joystick (Up/Down) and push ENTER.

ON/OFF

On/Off button

Push ON/OFF at any time to turn the screen Off. The system continues to operate and to monitor vehicle position.

Push ON/OFF again to turn the screen back On. (The road safety caution screen is only displayed when the ignition is switched on.)

Note:

1. While under guidance, a prompt is displayed when the system is turned back On. See **Continue trip** on page 4-1.
2. The audible instructions are not turned off. (To mute the audible instructions, see **Volume adjustment** on page 1-11.)

Using the controls (continued)

**Map button**

The Map button has the following functions.

- Returns to the map display, showing the current vehicle position, from any other screen
- After scrolling, returns the map display to the current vehicle position.
- While under guidance, toggles between map and arrow view

**Scale control**

The Scale control (Up/Down) has the following functions.

- Changes the scale (Reduce/Enlarge) when a map screen is displayed
- Displays more pages (Previous/Next) of text information when the scrolling arrows are displayed at the top or bottom of the screen.

Volume adjustment

Note: These controls are on the sound system control panel.

The sound output during voice guidance can be adjusted as described below. The current setting is displayed during the adjustment procedure.


'Mute' – Mutes voice guidance

'-3' to **'+3'** – Changes the navigation sound volume from minimum ('-3') to maximum ('+3').

'Max' – Mutes audio sound (front and rear speakers) during voice guidance

Note:

1. Navigation sound will be heard from the front speakers only
2. During voice guidance, the audio sound will be heard at a preset level (unless muted).
3. During voice guidance, the audio sound from the rear speakers will be limited to volume setting 15.



The procedure for changing the setting is as follows

1. Push **MODE (A)** until the sound system display shows 'NAV Audio'
2. The current setting for the navigation system is displayed.
3. Turn the Volume control (**B**) until the desired setting is shown. (The normal audio display resumes automatically or when any sound system button is pushed.)

1-12 Introduction and controls

Text input




Character Input

Use the Joystick (Up/Down, Left/Right and diagonal) to highlight the first character in the name and push ENTER. Repeat for each character in turn. As characters are entered, only the characters available to complete the name (or similar names) are shown in black.

To delete a character, highlight 'Delete' and push ENTER. The last character input will be deleted. To input a space, highlight 'Space' and push ENTER.

A list of possible names (for example streets, cities, or motorways) is displayed. See Selection screen example.

Note: During character input, it may be necessary to use the Joystick diagonal movement to select certain characters, depending on the characters available.




Selection screen example

The screen shows the list of possible names from the characters entered. The list reduces in length as more characters are entered, until the required name appears in the lower text area of the character input screen.

Highlight the item required using the Joystick (Up/Down) and push ENTER. The next screen is displayed.

Note: The required item can be selected at any time from the list using the Joystick and Scale control. (Use the Joystick to scroll on to the second page before using the Scale control.)



Number Input

Use the Joystick (Up/Down, Left/Right and diagonal) to highlight the first digit in the number and push ENTER. Repeat for each digit in turn.

To delete a digit, highlight 'Delete' and push ENTER. The last digit input will be deleted.

When all the digits have been input, highlight 'Done' and push ENTER. The next screen is displayed.

Note:

1. If a house number is not required, highlight 'Done' and push ENTER.
2. If the number is not in range, a message will be displayed. The number must be input again in the range shown.

Main features of the system

Memory points

These are points (map locations) that can be stored in memory by the user with a personalised nametag (e.g. Doctor, Office) for subsequent selection as route destinations or way points. The following input methods can all be used to store memory points: address, intersection, points of interest, map cursor location, recent destinations and local points. See **Destination menu** on page 3-4.

Way points

Way points are held in a list and can be used to divide a route into a number of sections, the route being calculated one section at a time. The user selects the first and last way points to be visited along the route. The order in which the intermediate way points are visited is determined during route calculation, based on the current calculation method (e.g. Shortest Time). A maximum number of eight way points can be held in the list. Also see **Using way points**.

Avoid roads

After setting up a route, one or more roads can be selected, from the route turns list, as roads to be avoided. The route is then recalculated avoiding the roads selected.

Using way points

The procedure for setting a route using way points is shown below.

- Enter the desired way point addresses. See **Set way points** on page 4-1. The way points are added to the way points list
- Select the way points to be visited first and last along the route. (The last way point is the ultimate destination.) Then set the route to the first way point. See **Way points** on page 3-6.
- After driving each section of the route, to set the route to each following way point, select **Next Way Point**. See **Main menu** on page 3-3
- One or more way points may be deleted from the list if required, see **Edit way points** on page 3-11. While under guidance the points can only be skipped, see **Skip way point** on page 3-13

Points of Interest (POI)

This is a database of useful names and addresses held on the map DVD. The information can be displayed on the screen and sorted by category. A POI can be selected from the list and used as a route destination, memory point or way point

Local points – This allows a POI category to be displayed sorted by distance from the current vehicle location, and provides a quick method of selecting points of interest near at hand.

Voice guidance

One or more audible instructions and/or chimes will be heard for each manoeuvre point along the route. Three levels of guidance are available (minimum, normal and maximum) which are selected from the Setup menu, see **Voice prompt** on page 3-8. Voice guidance will be muted if a phone call is in progress.

Screen guidance

There are three methods of screen guidance available: map, arrow, and hybrid. The desired method can be selected from the Setup menu. For all three methods, as the route is followed, current vehicle location, next turn information, and distance and estimated time to the destination are displayed.

For further information, see **Screen guidance** on page 4-3.

2-2 Quick reference

Route setting example

This is a simple example showing how to use the basic features of the system to set a route. It describes each screen in turn and explains how to use the controls. For information relating to the other features of the system, see the relevant section in the handbook.

Note: Before using the system, check that the correct map DVD is loaded, see **Loading the map DVD** on page 15.



Initialisation

If the Jaguar screen is displayed, push ENTER. The road safety caution screen is displayed.



Road safety caution


The caution screen shows the following information:

Most functions are inhibited while the vehicle is in motion.

Please read the handbook for operating instructions.

Always obey traffic regulations.

To use the system, push ENTER. The screen shows the map display.



Map display

The map display shows the current vehicle position. Push MENU to display the Main menu.

Route setting example (continued)




Main menu

The screen shows the Main menu options

- Destination
- Setup
- Option
- Route

To display the Destination menu, highlight 'Destination' using the joystick (Up/Down), and push ENTER.



Destination menu

The Destination menu is displayed, showing the methods available for entering a destination

To input an address, highlight 'Address' using the joystick (Up/Down), and push ENTER.




Address Input

To input the required street name, highlight 'Street Name Input' using the joystick (Up/Down), and push ENTER.

2-4 Quick reference

Route setting example (continued)



Street name input

The character input screen is displayed for input of the street name required. See **Character Input** on page 1-12.

A list of possible streets is displayed. The list reduces in length as more characters are input until the required name appears in the lower text area of the screen.

Highlight the street required using the joystick (Up/Down), and push ENTER for input of the house number.

Note: Enter the name of the street only (Do not include 'Street', 'Road' or other similar word.)




House number input

The number input screen is displayed for input of the house number required. See **Number Input** on page 1-12.

When the number has been input, highlight 'Done' using the joystick (Up/Down, Left/Right, and diagonal), and push ENTER to display the list of possible cities.

Note:

1. The number input must be within the range shown. If a house number is not required, highlight 'Done' and push ENTER.
2. If the street does not have house numbers held on the map DVD, the number input screen will not be shown.



Select city

The list includes all the cities where the address input (house number and street) occurs.


Highlight the city entry required using the joystick (Up/Down). Push ENTER to display the location details and confirm the destination.

Route setting example (continued)

**Confirm destination**

The screen shows the location details of the address input and the setting options available. To confirm the destination, highlight 'ENTER to Proceed' using the joystick (Up/Down), and push ENTER to calculate the route.

Route calculation - The screen shows 'Calculating' while the route is being calculated. When the calculation is complete, the screen shows the guidance display.

**Route guidance****WARNING:**

Only operate, adjust or view the system when it is safe to do so.

The route is displayed according to the currently selected guide method (map, arrow or hybrid).

Drive off, following the voice guidance given by the system until the destination is reached.


Note: If the vehicle is not at the start of the route, the screen will show 'Please Proceed' until the route is reached.

**End of route**

As the vehicle approaches the end of the route, 'DESTINATION' is shown on the screen. This is confirmed by voice guidance. After arrival at the destination, the screen shows the destination address. The system is then ready for further use.

2-6 Quick reference

Menu structure



Getting started



Initialisation

Caution: Do not leave the ignition on for long periods with the engine not running.

The system is powered on when the ignition switch is turned to position 'I'. After a short pause, the Jaguar screen with the digital clock is displayed. Push ENTER to continue. The road safety caution screen is displayed.



Road safety caution

The caution screen shows the following information.

Most functions are inhibited while the vehicle is in motion.

Please read the handbook for operating instructions.


Always obey traffic regulations.

To use the system, push ENTER. The screen shows the map display. If the system is not used, the Jaguar screen will be displayed again after a time delay.

Note: If route guidance was in progress when the ignition was switched off, a prompt is displayed. See *Continue trip* on page 4-1.

3-2 Operation

Getting started (continued)



Map display

The map display shows the current vehicle position. The panel controls (while the vehicle is not under guidance) have the functions shown.

Panel controls

Menu button – Displays the Main menu, see **Main menu** on page 3-3

Clear button – Push and hold CLEAR for two seconds to change the map orientation (north or vehicle heading to the top of the screen;

Scale control – The Scale control (Up/Down) has the following functions:

- Changes the scale (Reduce/Enlarge) when a map screen is displayed.
- Displays more pages (Previous/Next) of text information when the scrolling arrows are displayed at the top or bottom of the screen.


Joystick – Use the joystick (Up/Down, Left/Right, and diagonal) to scroll the map as required.

Enter button – After scrolling the map, pushing ENTER shows the map cursor location details highlighted in a text box. Push ENTER again to set as a destination, memory point or way point. See **Confirm destination** on page 4-1

On/Off button – Push ON/OFF to turn the screen Off. The system continues to operate and to monitor vehicle position. Push ON/OFF again to turn the screen back On.

Map button – The Map button has the following functions:

- Returns to the map display, showing the current vehicle position, from any other screen
- After scrolling, the map display returns to the current vehicle position



POI Icon display

When selected, the map shows the location of any points of interest in the currently chosen categories. An icon can be selected as a destination, memory point or way point by scrolling the map and pressing ENTER, see **Enter button**.

Note: Icons are only displayed at the maximum zoom level in of 1/20 mile (100 metres) and the next zoom level out.

Main menu



Main menu

The menu is displayed by pushing MENU. Select the option required.

- Destination
- Setup
- Option
- Route
- Next Way Point

These options are described in the following pages.

Next way point

When using way points select this option to calculate the route to the next way point in the list, using the current calculation method. See **Way points** on page 2-1

Note:

1. Some of the options from the Destination menu are not available while driving (not under guidance). These are Address, 'Intersection' and 'Points of Interest'
2. The Setup and Option menus are not available while driving (whether under guidance or not)
3. The Route menu is only available while driving under guidance
4. While driving under guidance, none of the options on the Destination menu are available
5. 'Next Way Point' is only available after a way point has been entered in the way point list.

3-4 Operation

Destination menu



Destination

Select the option required

- Address
- Intersection
- Points of Interest
- Map Cursor
- Recent Destination Points
- Memory Points
- Local Points
- Way Points

These options are described in the following pages

Note:

1. For information on entering text, see **Text Input** on page 1-12
2. For destinations outside the detailed map area, see **Long-haul areas** on page 4-5



Address

Select the option required

Street name Input – Input and select the street name, followed by the house number. (If the street name is not unique select a city (and district if known) from the options displayed.) The screen shows the location details of the address input, see **Confirm destination** on page 4-1

City name Input – Input a city name and select the city (and district if known), followed by the street name details, see above

Note: The system defaults to the city where the vehicle is located.



Intersection

Select the option required

Street name Input – Input and select the street names forming the intersection. (If the intersection is not unique, select a city and intersection from the options displayed.) The screen shows the location details of the intersection input, see **Confirm destination** on page 4-1

City name Input – Input a city name and select the city (and district if known), followed by the street name details, see above

Note: The system defaults to the city where the vehicle is located.

Destination menu (continued)




Points of interest (POI)

Select the option required:

Place name input – Input the POI name and select the item required from the list displayed

Category list – Select an item from the list of categories displayed, and select or input the city required. Select or input the POI name required.

The screen shows the location details of the point input, see **Confirm destination** on page 4-1



Map cursor

Select the option required

Directly on map – Scroll the map until the desired location is under the cross-wire marker and push ENTER. The screen shows the location details highlighted in a text box, push ENTER to select

Within a city – Input and select the city name, and scroll the map as described above.

The screen shows the location details of the selected point, see **Confirm destination** on page 4-1

Note:

1. The screen may show 'No digitised road exists in this area. Please select another area'
2. This function can be used for guidance to a city centre




Recent destination points

Select the item required from the list of recent destinations displayed. The screen shows the location details of the selected point, see **Confirm destination** on page 4-1

A maximum of 20 recent destinations can be stored. When this number is exceeded, the oldest destination in the list is deleted each time a destination is set. If the same destination has been set more than once, it will only appear once in the list.

3-6 Operation


Destination menu (continued)



Memory points


Select the item required from the list of memory points displayed. The screen shows the location details of the point selected, see **Confirm destination** on page 4-1.

A maximum of 90 memory points can be stored. When this number is exceeded the point at the bottom of the list is deleted each time a new point is entered.



Local points

Select an item from the list of POI categories displayed. The screen shows the list of points of interest in that category, sorted by distance from the current vehicle location. Select the point required. The screen shows the location details of the point selected, see **Confirm destination** on page 4-1.



Way points

Note: Before using this procedure, the desired locations must be entered and added to the way points list.

The screen briefly shows 'System is calculating the best path of destinations'. The screen then shows 'Confirm Destination' with the first way point location details. Select the option required from the list displayed:

Enter to Proceed - When the desired first and last way points have been chosen, select this option to set the route to the first way point. See **Calculation** on page 4-1.

Way points list - This option is used to set the first and last way points for the current route. Select an item from the list of way points displayed and push ENTER. Follow the on-screen prompts as required.

Setup menu



Setup

Select the option required:

- Display Colour
- POI Icon
- Map Direction
- Language
- Voice Prompt
- Guide Method
- Auto Reroute
- Calculation Method
- Time Zone
- Summer Time

These options are described in the following pages.

Display colour

Select the option required.

- Day
- Night
- Auto

Day and Night – The appearance of the display is adjusted to suit current driving conditions

Auto – The Day setting is automatically selected with the exterior lighting switch in the Off position. The Night setting is selected with the switch in any other position, unless the instrument dimmer switch is in the 'override' position

Note: For vehicles with day time running lights, use the Day and Night options only

POI Icon

Select the option required

- Show
- Hide
- Edit

Show and Hide – The selected POI icons can either be shown on the map or hidden, as required

Edit – The screen shows the list of available POI icons. Select the items required for display on the map. No more than three icons may be selected at any one time. Select Return to continue.

Map direction

Select the option required

- Heading Up
- North Up

The map can be displayed with either north or vehicle heading to the top of the screen

Select Return to continue

3-8 Operation

Setup menu (continued)

Language

Select the language required:

- English
- Deutsch (German)
- Français (French)
- Italiano (Italian)
- Nederlands (Dutch)

The language used for the on-screen text and voice instructions can be selected from the list displayed.

Select 'Return' to continue without change.

Note: After changing the language, the road safety caution is displayed in the new language. Push ENTER to continue. If the vehicle is in a long-haul area, a second caution will be displayed.

Voice prompt

Select the option required:

- Min.
- Normal
- Max

The desired number of audible instructions and/or chimes given for each manoeuvre can be chosen. The actual number of instructions given will vary according to the particular route being followed.

Guide method

Select the option required:

- Hybrid
- Arrow
- Map

The desired screen guidance method can be selected, see **Screen guidance** on page 4-3.

Auto reroute

Select the option required:

- On
- Off

If Auto Reroute is On and the vehicle deviates from the highlighted route, the route will automatically be recalculated. If Auto Reroute is Off, the route will not be recalculated, but guidance will resume if the vehicle rejoins the highlighted route.

Calculation method

Select the option required:

- Shortest Time
- Maximise Motorways
- Minimise Motorways
- Minimise Toll Roads

The route calculation method can be changed as required.

Select 'Return' to continue without change.

Note: Only one method can be selected.

Setup menu (continued)

Time zone

Select the time zone required:

- EU Central
- GMT
- US Eastern
- US Central
- US Mountain
- US Pacific

Choose the correct time zone for the current vehicle position. (If the time zone is incorrectly set, the clock may not show the right time.)

Select 'Return' to continue without change.

Summer time


Select the option required:

- Off
- On

At the start of the summer time period, select On. The clock will be advanced by one hour. When summer time ends, select Off.

3-10 Operation

Option menu



Option

Select the option required

- Edit Memory Points
- Edit Recent Destination Points
- Edit Way Points
- GPS Information
- System Information

These options are described in the following pages.



Edit memory points

Select the item required from the list of memory points displayed. The screen then shows the location details of the selected point. Select the option required from the list displayed.

Change name & phone number – The character input screen is displayed to change the name. When completed, select 'Save'. The number input screen is displayed to change the phone number. When completed, select Done.

Delete from memory points – The screen shows 'Are you sure you want to delete? Push ENTER to continue'.

ENTER to return – Continue without deleting any points.



Edit recent destination points


Select the item required from the list of recent destination points displayed. The screen then shows the location details of the selected point. Select the option required from the list displayed.

Delete from recent dest. points – The screen shows 'Are you sure you want to delete? Push ENTER to continue'.

Delete all – The screen shows 'Are you sure you want to delete? Push ENTER to continue'.


ENTER to return – Continue without deleting any points.

Option menu (continued)



Edit way points

The screen shows the list of current way points. One or all of the way points can be deleted. Select the way point required and follow the on-screen prompts as required.



GPS Information


The screen shows the current vehicle location, current vehicle position (latitude, longitude and elevation), and the number of GPS satellites in contact with the system.

Push ENTER to continue

GPS symbol – The GPS satellite symbol is shown on the map display in one of three colours. These are explained below.
Grey: no satellite signals are being received.

Red: insufficient satellite signals are being received for accurate map positioning.

Green: satellite map positioning is functioning normally



System information

The screen shows the following information: database area, database code and software version.

Push ENTER to continue

3-12 Operation

Route menu



Route

Select the option required


- Cancel Current Destination
- Avoid Roads
- Change Calculating Method
- Skip Way Point

These options are described in the following pages.



Cancel current destination

The screen shows the prompt 'Are you sure you want to delete the current destination? Push ENTER to continue'. When ENTER is pushed, the route will be deleted and the map showing the current vehicle position will be displayed.



Avoid roads

Select the item required from the list of turns displayed. Select the option required from the list displayed.

Reroute – When the desired road(s) have been chosen, select this option to recalculate the route. See Calculation on page 4-1.

Continue to avoid roads – The turns list is displayed again to select another road to be avoided.

Route menu (continued)



Change calculating method

Select the option required.

- Shortest Time
- Maximise Motorways
- Minimise Motorways
- Minimise Toll Roads

After selecting the desired method, the screen shows the location details of the current destination. Select 'Push ENTER to Proceed' to continue

Note: Only one method can be selected at a time



Skip way point

The screen shows the location details of the next way point on the route. Select the option required:

ENTER to proceed – When the desired way point has been chosen, select this option to recalculate the route.

See Calculation on page 4-1

Way points list – To skip a different way point, select an item from the list of way points displayed and push ENTER. The Confirm Destination screen is displayed again.

Note: Before the confirm destination screen is displayed, the screen may show 'Are you sure you want to change the destination? Push ENTER to continue'. The screen will then show 'System is calculating the best path of destinations followed by the Confirm Destination screen.'

3-14 Operation

Route calculation



Confirm destination

The screen shows the location details for the address or point entered. Select the option required from the list displayed

ENTER to proceed – Sets a route to the chosen location, see **Calculation**.

Map – Displays the map showing the entered location, which can be adjusted by scrolling the map if required. Push ENTER to set a route to the location, see **Calculation**.

Set memory point – Saves the location as a memory point. The character input screen is displayed. Input the name required for the point, and select **Save**.

Set way point – Saves the location as a way point. The list of current way points is displayed. Push ENTER to add the chosen location. (To set a route using way points, see **Using way points** on page 2-1.)




Continue trip

If the vehicle has been stopped and the ignition switched off while under guidance, when the ignition is switched on again the screen will show the destination details and **ENTER to Proceed**, see **Calculation**.

Note:

1. Push **CLEAR** if guidance for the remainder of the route is not required. The route will be cancelled and the map showing the current vehicle position will be displayed.
2. If the screen has been turned off using the ON/OFF button, the same procedure applies when the screen is turned on again.
3. For operation in long-haul areas, see **Long-haul areas** on page 4-5.



Calculation

The screen shows 'Calculating' and the destination details while the route is being calculated. When the calculation is complete, the start of the route is displayed.




WARNING:

While the route is being calculated, the screen may show one of the following warnings, which must be observed.

1. 'Destination is located on a restricted road. Please follow traffic regulations.'
2. 'Destination is located on a restricted or private area. You may need permission. Push ENTER to continue.'

4-2 Route calculation and guidance

Route guidance



Driving off



WARNING:

Only operate, adjust or view the system when it is safe to do so.

The screen shows the current vehicle position and the route highlighted. As the route is followed, current vehicle location, next turn information, and distance and estimated time to the destination are displayed. The panel controls (while the vehicle is under guidance) have the functions shown.

Drive off, following the voice guidance given by the system until the destination is reached.

Note: If the vehicle is not at the start of the route, the screen will show 'Please Proceed' until the route is reached.

Panel controls

Menu button - Displays the Main menu, see Main menu on page 3-3

Clear button - Push and hold CLEAR for two seconds to change the map orientation (north or vehicle heading to the top of the screen).

Scale control - Use the Scale control (Up/Down) to change the scale of the map (Reduce/Enlarge)

Joystick - Use the Joystick (Up/Down, Left/Right, and diagonal) to scroll the map as required.

Enter button - After scrolling the map, pushing ENTER shows the map cursor location details highlighted in a text box. Push ENTER again to set as a destination, memory point or way point. See **Confirm destination** on page 4-1

On/Off button - Push ON/OFF to turn the screen Off. The system continues to operate and to monitor vehicle position. Push ON/OFF again to turn the screen back On. See **Continue trip** on page 4-1.


Map button - The Map button has the following functions.

- Returns to the map display, showing the current vehicle position, from any other screen.
- After scrolling, the map display returns to the current vehicle position.
- In hybrid view, toggles between map and arrow view

Repeat button - Repeats the last audible instruction. If the manoeuvre point has been passed, the audible instruction for the next manoeuvre point will be heard.

List button - Lists the turn information for the calculated route, see **Turns list** on page 4-4

Screen guidance




Map view

The screen shows the map display with the route highlighted. As the route is followed, the map scrolls automatically keeping the current vehicle position on the screen.


Screen guidance selection

The guidance method required, is selected from the Setup menu. See **Guide method** on page 3-8



Arrow view

The route is shown in diagrammatic form. As the vehicle approaches each manoeuvre point, a detailed view of the next junction is shown and a countdown bar graph is displayed.



Hybrid view

The screen normally shows the map display with the route highlighted. As the vehicle approaches each manoeuvre point, the arrow view screen with the countdown bar graph is displayed.

4-4 Route calculation and guidance

Additional guidance features



Route	Maneuver List
↘	PRESTON NEW ROAD / A5 0.3 mi
↑	PRESTON NEW ROAD / A5 0.2 mi
↙	2.0 mi
↘	UNNAMED RD 0.4 mi
↘	WATERLOO ROAD / A507 0.7 mi
↘	LYTHAM ROAD / B5262 0.0 mi
↘	WATERLOO ROAD / A507 0.2 mi
↘	PROMENADE / A504 0.5 mi

Turns list

When LIST is pushed, the list of turns on the current route is displayed. The location of the turn action to be taken and distance to the next turn are shown.

Use the Joystick (Up/Down) to scroll through the list. At the end of the list, the destination details are shown.

As the list is scrolled, each item is shown highlighted. When ENTER is pushed, the corresponding turn instruction is displayed. Following this selection, the Joystick (Up/Down) can be used to display the turn instructions (Previous/Next) from the turn selected.

Note: The Scale control (Up/Down) can be used to display the turns list a page at a time.

Long-haul areas



Long-haul area caution


A long-haul area is an area (or country) outside the detailed coverage area of the map disc currently loaded in the navigation unit.

The caution screen shows the following information.

You are outside the detailed coverage area of the map disc currently loaded in the navigation unit.

Guidance is limited to major roads. See handbook.

This caution is displayed when the system recognises that the vehicle is in a long-haul area. It is also displayed each time the system is turned on while the vehicle remains in a long-haul area, and when the screen language is changed.




Road coverage

In long-haul areas, only the major road networks are covered by the system. The countries covered can be seen on the screen by selecting the highest zoom level, and are shown in yellow. By selecting lower zoom levels, details of the major road coverage in a particular country can be seen.

Route guidance

In long-haul areas normal route guidance is available, but only within the major road network shown on the map.

Caution: If the vehicle leaves the route, recalculation will not be possible away from the major road network. If a route is recalculated, limitations in the map data may result in an unnecessary detour back to the original route being made.



Destination setting

Select 'Address' from the Dest nation menu, and enter a city name. In the list displayed, cities in long-haul areas are shown with 'City Centre' after the city name. For the complete list of long-haul cities, see [Long-haul cities](#) on page 4-7. Select the city required. The screen briefly shows 'Street Input is not available. City Centre' will be set as destination. The screen then shows the details of the city selected.

Note:

1. Destinations within long-haul areas cannot be set to an exact street location by the address entry method described above.
2. Destinations may also be set by scrolling the map, or by selecting a POI rest area.

4-6 Route calculation and guidance


Long-haul areas (continued)



Selecting stored destinations

Owing to limitations in the digitised map data, it may not always be possible to set a destination in a long-haul area using a previously stored location (e.g. recent destination or memory point). This can occur when the location was originally stored while the detailed map disc for that area was loaded.

Any items that are currently unavailable are shown shaded when the list is displayed. If a shaded item is selected a message is shown briefly on the screen.



Rest areas

Details of rest areas (e.g. motorway service areas and car parks) can be seen by selecting the 'Rest Area' category of Points of Interest (or Local Points). All the long-haul areas covered by the system are included and a rest area can be selected as a destination.



Rest area icon – The icon will be displayed on the map at each rest area location when the 'Show POI Icon' option is selected.



Rest area details

All rest areas are listed, sorted by distance from the current vehicle location. The details for each area include the motorway (where applicable) and the country in which the rest area is situated.

Note:

1. In long-haul areas, 'Rest Areas' is the only Points of Interest category available.
2. The facilities available at some rest areas (e.g. car parks) may be very limited.

Route calculation and guidance 4-7

Long-haul cities

Note: The list of long-haul cities includes all the countries covered by the system. Ignore the country or countries covered by the map disc that is currently loaded, as normal route guidance will be available

Austria	France	France (cont'd)	Germany	Germany (cont'd)
Bregenz	Amiens	Metz	Augsburg	Mönchengladbach
Dornbirn (Rheinthal)	Angers	Monaco (Monaco)	Freiburg im Breisgau	Münster
Graz	Annecy	Montbéliard	Karlsruhe	Oberhausen
Innsbruck	Avignon	Monte-Carlo (Monaco)	Mannheim	Solingen
Klagenfurt	Bayonne	Montpellier	München	Wuppertal
Linz	Besançon	Mulhouse	Nürnberg	Bremen
Salzburg	Bethune	Nancy	Stuttgart	Hamburg
St. Pölten	Bordeaux	Nantes	Darmstadt	Hannover
Vienna	Brest	Nice	Frankfurt am Main	Kiel
Villach	Caen	Nîmes	Kaiserlautern	Berlin
Wels	Calais	Orléans	Kassel	Chemnitz
	Cannes	Paris	Koblenz	Dresden
Belgium	Chambery	Pau	Ludwigshafen am Rhein	Erfurt
Antwerpen	Clermont-Ferrand	Perpignan	Mainz	Leipzig
Arlon	Dijon	Poitiers	Saarbrücken	Magdeburg
Brugge	Doua	Reims	Welsbaden	Potsdam
Brüssel	Dunkerque	Rennes	Aachen	Rostock
Charleroi	Grenoble	Rouen	Bielefeld	Schwerin
Gent	Hagondange	Saint-Etienne	Bochum	Weimar
Hasselt	Le Havre	Saint-Nazaire	Bonn	
Leuven	Le Mans	Strasbourg	Dortmund	
Liège	Lens	Thionville	Duisburg	
Mechelen	Lille	Toulon	Düsseldorf	
Mons	Limoges	Toulouse	Essen	
Namur	Lorient	Tours	Gelsenkirchen	
Oostende	Lyon	Valence	Köln	
Wavre	Marseille	Valenciennes	Krefeld	
	Menton		Leverkusen	

4-8 Route calculation and guidance

Long-haul cities (continued)

Italy	Italy (cont'd)	The Netherlands (cont'd)	United Kingdom	United Kingdom (cont'd)
Bari	Salerno	's Hertogenbosch	Aberdeen	Northampton
Bergamo	Taranto	Leeuwarden	Bath	Norwich
Bologna	Terni	Leiden	Birmingham	Nottingham
Bolzano	Torino	Lelystad	Bradford	Oxford
Brescia	Trento	Maastricht	Brighton	Peterborough
Ferrare	Trieste	Middelburg	Bristol	Plymouth
Firenze	Varese	Nijmegen	Cambridge	Portsmouth
Foggia	Venezia	Rotterdam	Cardiff	Reading
Forlì	Verona	Tilburg	Carlisle	Sheffield
Genova	Vicenza	Utrecht	Coventry	Southampton
Latina	Vatican City	Zaanstad	Derby	Stoke on Trent
Lecce	San Marino	Zoetermeer	Dover	Sunderland
Livorno		Zwolle	Dundee	Swansea
Milano	Luxembourg		Edinburgh	Wolverhampton
Modena	Luxemburg	Switzerland	Exeter	York
Monza		Basel	Fishguard	
Napoli	The Netherlands	Bern	Folkstone	
Novara	Almere	Biel	Glasgow	
Padova	Amersfoort	Geneve	Harwich	
Parma	Amsterdam	Lausanne	Holyhead	
Perugia	Apeldoorn	Lugano	Inverness	
Pescara	Arnhem	Luzern	Ipswich	
Piacenza	Assen	Neuchatel	Kington upon Hull	
Pisa	Breda	St. Gallen	Leeds	
Prato	Den Haag	Winterthur	Leicester	
Ravenna	Dordrecht	Zug	Liverpool	
Reggio Calabria	Eindhoven	Zürich	London	
Reggio Emilia	Enschede	Vaduz (Liechtenstein)	Manchester	
Rimini	Groningen		Middlesbrough	
Roma	Haarlem		Newcastle upon Tyne	

Index

About this handbook	1-2
Additional guidance features	4-4
– turns list	4-4
Control panel	1-5
Destination menu	3-4
– address	3-4
– intersection	3-4
– local points	3-6
– map cursor	3-5
– memory points	3-6
– points of interest	3-5
– recent destination points	3-5
– way points	3-6
Getting started	3-1
– initialisation	3-1
– map display	3-2
– panel controls	3-2
– POI icon display	3-2
– road safety caution	3-1
How the system works	1-1
Loading the map DVD	1-5

Long-haul areas	4-5
– destination setting	4-5
– long-haul area caution	4-5
– long-haul cities	4-7
– rest areas	4-6
– road coverage	4-5
– route guidance	4-5
– selecting stored destinations	4-6
Main features of the system	2-1
– avoid roads	2-1
– local points	2-1
– memory points	2-1
– points of interest	2-1
– screen guidance	2-1
– using way points	2-1
– voice guidance	2-1
– way points	2-1
Main menu	3-3
Menu structure	2-6
Option menu	3-10
– edit memory points	3-10
– edit recent destination points	3-10
– edit way points	3-11
– GPS information	3-11
– system information	3-11

Index

Route calculation	4-1	Setup menu	3-7
– calculation	4-1	– auto reroute	3-8
– confirm destination	4-1	– calculation method	3-8
– continue trip	4-1	– display colour	3-7
Route guidance	4-2	– guide method	3-8
– driving off	4-2	– language	3-8
– panel controls	4-2	– map direction	3-7
Route menu	3-12	– POI icon	3-7
– avoid roads	3-12	– summer time	3-9
– cancel current destination	3-12	– time zone	3-9
– change calculating method	3-13	– voice prompt	3-8
– skip way point	3-13		
Route setting example	2-2	Text input	1-12
Safety information	1-2	Using the controls	1-10
Screen displays	1-6	– volume adjustment	1-11
– arrow view screens	1-7	Using the system	1-2
– map screens	1-6	– city name lists	1-4
– menu screens	1-9	– clock	1-4
– screen symbols	1-8	– errors in vehicle position	1-3
– scrolling indicators	1-9	– estimated time to destination	1-4
Screen guidance	4-3	– Jaguar dealership locations	1-4
– arrow view	4-3	– languages and distance units	1-4
– hybrid view	4-3	– map DVDs	1-4
– map view	4-3	– reception of GPS signals	1-3
		– road junction layouts	1-4
		– route guidance precision	1-3
		– screen cleaning	1-4

JJM 10 05 14/10



This book is printed on paper that originates from sustainable forests, is recyclable, bio-degradable and acid free.
The wood pulp is chlorine-free and the effluent water is purified before being discharged.